INFORMATION REPORT	OF PAGE FOR SPECIAL CONTROLS, IF ANY This material contains information affecting the National Defense of the United States within the meaning of the Espionage Laws, Title 18, U.S.C Secs. 783 and 794, the transmission or revelation		
CENTRAL INTELLIGENCE AGENCY	of which in any manner to an unauthorized p son is prohibited by law.		
USSR			
	DATE DISTRIBUTED		
Navigational Instructions on River Yenisei	31 January 1958 NO. OF PAGES NO. OF ENCLS.		
Economic Control of the Control of t	1		
Linda	SUPPLEMENT TO REPORT #		
THIS IS LINEVALUATED INFORM	MATION		
The Office of Naval Intelligence furnished th	e following information to CIA		
for IAC dissemination in accordance with para	graph 3c of NSCID No 7		
NAVY Review Completed			
IAVY Review Completed			

NO DISSEM ABROAD

LIMITED: Dissemination limited to full-time employees of CIA, AEC and PE; and, within State and Defense, to the intelligence components, other office producing NIS elements, and higher echlons with their immediate supporting statis. Not to be disseminated to consultants, external projects or reserve personnel on short term active duty (excepting individuals who are normally full-time employees of CIA, AEC, PEI, State or Defense) unless the written permission of the originating affice has been obtained through the Assistant Director for Central Reference, CIA.

NAVY Review Completed

IKSTRUCTIONS

For Captains of Vessels Navigating Between the Kar Gite Strait and the Port of Imarka on the River Yenisei

1. General Regulations

- l. Before sailing for Igarka the compasses, electric or mechanical sounding apparatus also patent log must be in good working order. Special attention must be paid to adjusting of compasses. The Captain of a vessel proceeding to Igarka from the west through the Kara Gate Strait and back, is supplied by the Charterer with Soviet Nautical Charts Nos. 695, 696, 697, 698, with River Chart No. 945 sheets 1 to 6 and with the Book of Lights, Beacons and Radio Beacons of the region Kara Gate-Yenisei corrected according to the latest Nos. of Notifications to Navigators. The Captain navigating in the above-mentioned region must observe the regulations laid down in these instructions and follow the directions of the River Pilot concerning the sailing of the vessel along the fairway of the river.
- 2. The Captain of the vossel approaching the Kara Gate Strait from the west, informs the Agency of the Kara Ice Operations 24 hours before approaching the Strait and evaits their instructions as to the time of either entering the Kara Sea, or as to the place where he is to await improving of the ice situation, or as to the place where he is to meet the ice-breaker.
- 3. The Captain of the vessel sailing in the Kara Sea must keep the Agency of the Kara Ica Operations informed about the proceeding of his vessel, availing himself for that purpose of the services of the nearest radiostations (at Amderma or Dixon). The position of the vessel, the weather and sea conditions must be reported to the agency twice every day, at 3.00 a.m. and 3.00 p.m. Moscow time. We draw your particular attention to duly performance of this requirement. No charges are imposed by the radiostations for the above information.
- 4. In the event of encountering ice, the Captain of the vessel immediately notifies the Agency of the Kara Ice Operations, indicating the position of the vessel and the weather and sea conditions.
- the limits of fair navigation practice and in consideration of cailing in its conditions, with sufficient supplies of vessel equipment and stores, as well as with the necessary supplies of special emergency equipment (wooden girders, bolts, quick-setting cement, mats, cakum, plasters, etc.). No above materials are obtainable involvere in the region of the Kara Sea. All drainage facilities must be in good order and in constant readiness for action. The vessel must be also provided with sufficient provisions for 60 days and sufficient bunkers as per our order taking into account that no bunkers are available in Igarka or on the way to after passing surmansk.
- 6. All requests for ice-breaker assistance to help the vestsel through the ice must be addressed by the Captain to the Agency of Kara Ice Operations.

- 7. Any vessel in need of ice-breaker assistance through the ice must await instructions as to her movements from the Agency of Kara Ice Operations.
- 8. Havin encountered less the Captain of the vessel must adapt all necessary precautions, and as not to lamage the well of the vessel and especially the steering gear and the screen, and the

. It is also to be commerced, that:

- u) the vessel should ertem ice from "clear water" moving of "the lowest speed" and at normal (perpendicular) angle to the elre of the ice.
- c) should any damage of leakage be sustained by the vessel in the ice, immediate measures must be taken by the Captain to liquidate the damage or leakage and notice by radio must be sent to the nearest icebreaker and to the Agency of Kara Ice Cremiticus.
- 9. The Captain of the wassel must keep in mind that the ice-breaker can arrive at the place of the vessel location within 18 hours after the Captain's recigst for icebreaker assistance had been sent to the Agency of Hera Ice Operations. If in the opinion of the Agency the less attention is not one of emergency, a plane may be sent to investigate the ice zone and then the Agency will advise the vessel to prove a without aid to "clear water or to move to another region mane favourable from the point of vie of ice conditions.
- IO. Along the Yenisei Bay, sea-going vessels independently proceed to the anchorage of the river-pilot vessel in the estuare of the Yenisei River and back out of the river.
- 11. The Captain of the vessel sailing to Tgarka and back must take all necessary steps to organize in the best manner his sailing. manoeuvring in the ice and during storms, during invisibility and fors, and to protect his vessel and cargo from danger.

II. NAVIGATION ANDEST ICE AND IN CARAVANS (CONVOY)

- 12. The Captain of the vessel entering the lead of the icebreaker, must obey the orders of the Captain of the icebreaker concerning nevigation amidst ice and act accordingly. He is duty-bound to help the Captain of the icebreaker to effect a rapid and averageless passage through the ice zone.
- 13. Vessels following the icebreaker or moving in groups (caravans) must not get ahead of one another.
- 14. Vessels following the icetreaker must be prepared immediately to take up the command "Full Speed Astern" and to maintain the position "Bear Steady" when beginning to move backward.

governed by the following sound signals (see "Table" below) given either by a whistle or a siren. All signals, with the exception of signal No. 6, must be repeated by the vessels directly following the icebreaker in succession beginning with the one nearest to the icebreaker or to the vessel lesuing the signal.

The demands of the icobreaker expressed by these signals must be immediately carried out by the vessels.

The signals indicated in the Table are also used during group navigation of vessels in carevers and the Table must, therefore, be hung up on the bridge and in the Chart room, giving easy access to it of the Captain's vessels and enabling him to carry out the required manoeuvres without delay.

TABLE OF SOUND SIGNALS USED FURING CONVOYING VESSILS
THROUGH ICE

		The state of the s				
No.of	G4	Meaning of signals coming				
sig- nal	Signal	from escorting icebreaker	from escorted vessel.			
1.	en en en europijonie Silverie	Going forward, follow in my wake,	Going forward following icobreaker			
2.	-	Slow down your speed	Slowing down			
3	• • •	Full speed astern	Going full speed astern			
4.	-	Do not follow me, stop	Stopping			
5.		Attention Jammad in ite	Attention, jammed in ice			
6.	-	Be ready to accept ton.	Ready to take tow			
er Britisherstander a. A. de regati	2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	tow, then "helease com"	"Releasing tow"			
7.		Forward.Follow chammel	Going forward following channel.			
8,	,	Cut short interval	Cutting interval			
9.		Follow the destination	Following to destination			
IC.	e e •	Listen to radio	Listening to radio			
11,		Attention . Watch simula	Attention, watching signa			
12.	,	Come to anchor	Coming to unchor			
13.		Stop work till morning, or until more favourable conditions. During stops and until resumption of	Obeying			
	7 Page 1	and until resumption of work means "get meady"				
	•		70.97			

- NOTE: 1. The sound signals for passing clear of oach other in the ice, are the same as in "The Rules for Preventing Collisions of Vessels on Sea": one short sound meens: "changing my course to the right"; two short sounds signify: "changing my course to the left"; three short sounds "mo machinory is working astern".
- 2. When sailing during fog, mist, or snowstorm, sound signals provided by Article 15 of Rules for Preventing Collisions of Vessels on Sea", are to be applied.
- 5. The leading icebranker is the icebreaker sailing in front of one or of several vessels.
- 4. A line indicates a "prolonged sound", a dot stands for "a short sound" (see "Rules of International Code" or "Rules for Preventing Collisions of Wessels on Sea").
- 5. In group work of several icebreakers the Master icebreaker is the one whose machinery is more powerful and the orders issued by the latter should be carried out by the other icebreakers if there is no contrary orders from the Agency of Kara Ice Operations.
- 16. Should the Captain of any convoyed vessel fail to carry out the orders of the Captain of the leading icebreaker, the latter has the right to refuse further assistance to the convoyed vessel until his orders are fulfilled.
- 17. The Captain of the vessel availing himself of the services of the icebreaker for convoying her through the ice, thereby expresses consent to obey the regulations of these instructions which are in accordance with the "Rules for vessels convoyed by icebreakers through the ice", existing in the U.S.S.R.
- 18. When sailing in a group of vessels (caravans) the Captain of a vessel must observe the following rules:
- a) The speed of the vessel is regulated by the "leader" and the distance to be maintained between them is aslo indicated by the "leader".
- b) in fog the vessel must observe particular vigilance and issue fog signals after those coming from the vessel ahead.
- c) The vessel is not to leave the range of audability of the whistle of the vessel ahead.
- d) Then the fog is thick the leading vessel issues pecial instructions concerning the speed to be maintained, when the speed is diminished the leading vessel issues one long and one short whistles upon hearing which all vessels composing the caravan must also reduce their speed, when this signal is repeated the vessels reduce their speed still were, taking the necessary precautions to avoid collisions.
- e) The vessels of the caraten repeat the signal (- .) one after another,

- ing an important must extend dailing in a daravan or following an important must extend and the co-ordinates of the
 position of his vessel at an import. When the vessel is released
 by the icebreaker the daptate of the vessel can check the co-ordinates of his vessel with the so-ordinates of the place of release
 which are indicated by the despreamer.

 20. The Captain of the vessel converged by the icebreaker
 must be aware that neither the lidebraker, nor the Owner of the
 icebreaker, nor the Charterer was any responsibility for damage
 or other losses suffered by the conveyed tessel during or as a
 result of being convoyed through are or during manneauvres connected

to take all timels ain of the wessel is the prore under obligation

III. CONCERNING MAN CONVOY OF WISSIELS ALONG

21. The Cuptain of a second state the fenise River must send by reds to home the send of the river a request to send giver place of anchorage of a place of anchorage of a place of anchorage of a place of anchorage of the river a request to send giver place of the river a request to send giver place of the place of a procedure of arrival at learns the Usptain of the redsel must be guided with our general instructions of the leavage of our time chartered vessels in respect of the and on the redsel must also immediately inform Inflet Igarks of the leavage of the place of the vessel in the Kara Sea or in the estuary of the River after the above recognized and the noticies to be defined.

- tain of the vessel is to men in touch with the pilots the Capcarry out all orders of the Wester of the Pilot Stations located
- 23. Upon the arrival of miles alots vessel, the Captain of the result with 11 supply to the Master piles are a second of the draught. Energy was along the must state in the pilet sign and also certify safe pileting. pilots on board a sea-going wat fill in a pilot bill and wary case concarning his meering waslities - "How the captain that the Captain that the dropping
- 24. The Captain of the vessel should when necessary and upon request of the river pilot offer the latter free use of the radiostation for communication with the nearest loviet radiostation or pilot vessel.

 Approved For Release 2009/07/28: CIA-RDP80T00246A002900370001-9

- The river pilots convoy teasels only between the points from the estuary of the Yentsei River and to the Port Igarka, Within the limits of the port Igarka proper piloting service is rendered by the port pilot.
- 26. The Captain of a vesse saling along the Yenisei River obeys the orders of the river plant sensering sailing along river

The Captain of the vessel wanceuvres his machinery, while sailing on the river, in such a very as to avoid touching the edge of the channel or any other vessels.

27. During sailing along the river when fog or darkness sets in the Captain of the vessel, if a advised by the river pilot, must anchor the vessel in a safe piece until better visibility.

IV. RADIO COMMUNICATURA AND RADIO RAVIGATION SERVICE

- 23. The communicating radiostetions in the Kara Best are Am-
- 29. Vessels sailing in the Rack or Barents Sea east of the meridian 45° of eastern longitude and standard bilsteral radio communication with radio standard of liketima or Dixon, while vessels sailing on the Youisei can establish semannication with Igarka or
- 30. All radiograms addressed to the Agency of Kara Ice Operations or to the "Inflot" are transmitted through the above radiostations. Notices to Inflot Images, to be given through Igarka
 - 31. Information concerning coast

vanto:	Co-ordination of direction- al aerial	Calling :Working :Deily time for :Answers :Signals :frequency:observation of :calls of :of radio:E-cycles :vessels (at fre- :vessels :stations: :quency of 500 Ko):at a free :Moscow time :quency of
Amderma	,	UPM 304.8 All day round 500 Kc
Discon	73°30,4 II 80°24,4 E	УПЛ ПРV 324.3 " " 500 Кс
Igarka		<u>Y@P~5</u> U¥R-5 500 Ke

Bearings may be taken through the Dixon radio station by entering additional orders to the Agency of Kara Ice Operations not later than 30 minutes before beginning the taking of bearings. An additional charge of 6 france 25 ctm. 18 imposed for 1 minutes.

-7 -

of work of the Dixon Radio Station at bearings taking.

32. Radio beacons operate in Kara Sea at points: Capes Forwardky Nos (1000), Menshikoff, Kharasovol, Tonky (Thin), Belyi (Thite) Island, Island of Vilkitsky and Cape Leskin. Radio beacons the arit signals for hearings without preliminary orders at Loscow tire appointed for that purpose. The Radio beacons do not encor vertex appointed for that purpose.

ENFORMATION CONCLETING THE WORK OF RADIO REACONS IN THE MARK SEA.

Home of: Oc-ordi- :Onling :Working : Order and time of work scientic : signals of :fraquency: (Moscov time)

Liversky 70°26,8 N SC 417 All day round: at the belos 55°03,7 E 78 from OC to 05 min. trans-

57°36.5 E 34 304.6

All day round: at the beginning of every hour
from 00 to 05 mlm.transmits consecutively for
IO sec.the calling signal 30 and for 50sec.
a long dash.

All day round:

100	1088	
00 - 02		30-32
06-08		36 - 38
12-14		42-44
18-20		48-50
24-26		54 - 56

work is automatic.
During every minute consecutively from 00 to 10 and from 30 to 40 seconds the beacon transmits calling sizes!

and from 10 to

2Q 30 and from 40

to 60 seconds a

long dash. The bencon

works in a group with the

radio beacon Kharasovoi.

Tonky	69°51,5 1
	69°51,5' 1\ 61°06,2' 1\(\)

295,7

day round:

In fors

94-06	34-36
10-12	40-42
16-18	46-48
22-24	52-54
28-30	58-60

m clear weather

04-06,	34-	20
10-12	 40-4	12

minutes of every hour:
work is automatic.During
every minute consecutively
the beacon transmits from
00 to 10 sec. and from 30
to 40 sec. the calling
signal 3y and from

10 to 30 and from 40 to 60 sec. a long dash.

Kharasovoi 71°05,1 N 66°45,0 E

304.6

All day round:

In form

05-04	32-3	ſ
08-10	38-4	i
14-16		į
SOSe	50-5	
26-28		ŝ

In clear weather

02-04 32-34 08-10 .38-40

work is automatic. During IO sec. there is consecutive transmission of the calling signal gr

and for 50 sec. a long dash.
The beacon works in a group with the radio beacon Menshikoff.

Belyi	73°19,9 N	312,5	All day round:
	70⁰05,7 ∄	FV	<u>In fogs</u> 00-02 30-32 06-08 36-38 12-14 42-44 18-20 48-50 24-26 54-56
			In clear weather
			00 - 0 2 30-3 2 06-08 36-38 .
*			minutes of every hour. Nork is automatic.Du- ring every minute ther is consecutive trans- mission from 00 to 10 and from 30 to 40 .e- conds of the calling signal
			and from IO to 30 and from 40 to 60 seconds a long dash.
Vilkitsky	73°30,9 K	10 322.6	All day round:
	75°45,8 E	OF .	In fogs
	• ,		02 -0 4
			In clear weather
			02-04 32-34 08-10 38-40 .
			minutes of every hour. Work is automatic.Du- ring every minute there is consecutive trans- mission from 00 to 10 and from 30 to 40 se- conds of the calling signal 10 and from
			OF IO to 30 and from 40 to 60 seconds a long dash.
Leskin	72°19;0 H 79°33,5 E	<u>I</u> 420.0	All day round: from 00 to 05 minutes of every hour it transmits for IO sec. the calling signal IIII and then CP i for 50sec.

a long dash.

IMPORTANT WARNINGS:

The constal radio stations and radio parks or others cannot be used to locate vessels in the Kara Sec. and only the radio beacons indicated above in the last inctions can be used for that purpose.

33. Communication with the prior vessel anchored in the estury of the Menisei River is effected only for purposes of service, using the International rediction Code.

INFORMATION CONCERNING THE PIECE VERSEL

Vessel's calling signal	doordina- tes			Control of the Contro	and time of (Moscow time dicated)
Ye!TH UYGI	71°47;0 N- 71°41;0 N 83°00! 5- 83°30' E	50	Đ.	2300 0300 0700 1100 1500 1900	-0100 -0500 -0900 -1300 -1700 -2100

The radiostation of the pilot vessel enswers calls of vessels at a frequency of 500 Kc, exchange is made on scale of international working frequencies.

34. Weather and ice reports are transmitted by radio stations Amderma and Dixon;

INFORMATION CONCERNING WEATHER FORECASTING AND ICE TRANSMISSIONS

Name of Rad	io Calling signal	Morking Moscow time of Frequency Kc transmissions
Amderna	yn.: Upm	344.8 Daily at 1845-1915 in Russian
Dixon	JYII.:	324.3 Daily 1930-2000 in Russian.

35. The request for an itebreaker is made through the Agency of the Kara Ice Operations through the Dixon radiostation. The Agency of Kara Ice Operations will inform the Captain of the vessel, requesting the aid of on itebreaker, of the name of the icebreaker or the number of the plane which will render aid to the vessel in sailing amidst ice.

THEORIATION CONCERNING REPREASERS IN THE KARA SEA

Name of breaker	ice	Calli signa	og L	erequency	Time radi		ssels	
The "Kap	itan onin"	Va Nex			prd All	day ro	ound	•
The "Kar	pitan Be	y , y		require.		11	"	
The "Sa	al mjekov	THE THE				. ++	11	
The "Ka					n			

V. GENERAL PENA

36 All questions co by these "Instructions" a the vessel with the lagent perming operations of the readling amidst ice not covered taken up by the Captain of fee Operations; questions confin ports are subject to deci-

ALL-UNION ORGANIZATION
"SOVERACHT"